
Contents

Dedication	ii		
Preface	vii		
Summary	xi		
Rule 1. <i>Achieve a good quality melt</i>	1		
1.1	Background	1	
1.2	Melting	3	
1.3	Holding	3	
1.4	Pouring	4	
1.5	Melt treatments	5	
1.5.1	Degassing	5	
1.5.2	Additions	6	
1.6	Filtration	7	
1.6.1	Packed beds	7	
1.6.2	Alternative varieties of filters	8	
1.6.3	Practical aspects	8	
Rule 2. <i>Avoid turbulent entrainment (the critical velocity requirement)</i>	9		
2.1	Maximum velocity requirement	10	
2.2	The 'no fall' requirement	13	
2.3	Filling system design	15	
2.3.1	Gravity pouring of open-top moulds	15	
2.3.2	Gravity pouring of closed moulds	16	
2.3.3	Horizontal transfer casting	68	
2.3.4	Counter-gravity	72	
2.3.5	Surface tension controlled filling	75	
2.3.6	Inclusion control: filters and traps	78	
2.3.7	Practical calculation of the filling system	93	
Rule 3. <i>Avoid laminar entrainment of the surface film (the non-stopping, non-reversing condition)</i>	102		
3.1	Continuous expansion of the meniscus	102	
3.2	Arrest of vertical progress	103	
3.3	Waterfall flow	104	
3.4	Horizontal stream flow	104	
3.5	Hesitation and reversal	106	
Rule 4. <i>Avoid bubble damage</i>	108		
4.1	Gravity-filled running systems	111	
4.2	Pumped and low-pressure filling systems	112	
Rule 5. <i>Avoid core blows</i>	114		
5.1	Background	114	
5.2	Prevention	117	
Rule 6. <i>Avoid shrinkage damage</i>	120		
6.1	Feeding systems design background	120	
6.1.1	Gravity feeding	123	
6.1.2	Computer modelling of feeding	124	
6.1.3	Random perturbations to feeding patterns	124	
6.1.4	Dangers of solid feeding	125	
6.1.5	The non-feeding roles of feeders	125	
6.2	The seven feeding rules	126	
Rule 1:	Do not feed	126	
Rule 2:	Heat-transfer requirement	127	
Rule 3:	Mass-transfer requirement	128	
Rule 4:	Junction requirement	132	
Rule 5:	Feed path requirement	133	
Rule 6:	Pressure gradient requirement	138	
Rule 7:	Pressure requirement	140	
6.3	The new feeding logic	142	
6.3.1	Background	142	
6.3.2	The new approach	143	
6.4	Active feeding	145	
6.5	Freezing systems design	146	

6.5.1	External chills	147	10.2.1	Rectilinear systems	177
6.5.2	Internal chills	149	10.2.2	Cylindrical systems	178
6.5.3	Fins	150	10.2.3	Trigonal systems	179
			10.2.4	Thin-walled boxes	179
Rule 7.	<i>Avoid convection damage</i>	157	10.3	Location jigs	180
7.1	Convection: the academic background	157	10.4	Clamping points	180
7.2	Convection: the engineering imperatives	157	10.5	Mould design: the practical issues	181
7.3	Convection damage and casting section thickness	160	10.6	Casting accuracy	182
7.4	Countering convection	162	10.7	Tooling accuracy	183
			10.8	Mould accuracy	183
			10.9	Summary of factors affecting accuracy	186
			10.10	Metrology	186
Rule 8.	<i>Reduce segregation damage</i>	163			
Rule 9.	<i>Reduce residual stress (the 'no water quench' requirement)</i>	166	Appendix	188	
9.1	Introduction	166		The 1.5 factor	188
9.2	Residual stress from casting	166		The Bernoulli equation	189
9.3	Residual stress from quenching	167		Rate of pour of steel castings from a bottom-pour ladle	191
9.4	Distortion	172		Running system calculation record	191
9.5	Heat treatment developments	173		Design methodology for investment castings	194
9.6	Epilogue	174			
Rule 10.	<i>Provide location points</i>	175	References	195	
10.1	Datums	175	Index	199	
10.2	Location points	176			